


# Documentation of the installation springer - horse 5011



The order of the assembly:

- 1) Dig the monting hole.
- 2) Concret according to the instruction.
- 3) Check safety surface and secure the device against use (min 24 hours).

|                                                                |  |                                                                                                                                                                                                                          |                                                 |                   |
|----------------------------------------------------------------|--|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------|-------------------|
| Name:<br>5011 springer -documentation                          |  |                                                                                                                                                                                                                          | Drawing number:<br>5011 springer -documentation |                   |
| <b>BUGLO</b> Sp. z o.o.<br><br>WWW.BUGLO.PL                    |  | This technical documentation is the property of BUGLO SP. z o. o. and is protected by copyright. It is forbidden to use, copy, publish and distribute the materials in any form without the written permission of BUGLO. |                                                 | Page:<br><br>1 /1 |
| Designer:<br><br>P.K.                                          |  | Creation date:<br>2013-02-22                                                                                                                                                                                             | Scale:<br><br>1                                 | Material:         |
| path: X:\SINGLE BUGLO\5011\5011 Dokumentacja instalacji EN.idw |  |                                                                                                                                                                                                                          |                                                 |                   |